disassembly QUICK and SIMPLE!





To disassemble KONIK, once the wire is finished, simply unhook the cylindrical shape, remove it, place it in the appropriate pallet, and stack the drum together with the other empty drums.

Now, it can be shipped to the wire manufacturer, where it can be refilled for new use.





 Unhook the cylindrical shape









 Stack the drum togheter with the other empty drums





 Now it can be SHIPPED and REFILLED for new use!



